# Free Standing Dishwasher for 14 place settings and third tray for cutlery












function



MultiFlex-ECO function

3, wtih flexible cutlery tray

SmartSensor Extra Dry



### REFERENCE

REF: 40782501 EAN: 8421152153758

#### **FEATURES**

Free-standing dishwasher

Electronic control panel with display

Place settings: 14

Multifunctional third cutlery basket

Third sprayer

Washing programs: 8

Washing temperatures: 40°, 45°, 50°, 55°, 60°, 65°C

Dual Half load

Fast program 30 minutes

Eco Program

Full AquaStop safety system

Delay timer 1-24 hours

Adjustable upper basket (push-up)

Energy Class: A+++/A Noise level: 44 dBA

## **DIMENSIONS**

Product height (mm): 845 Product width (mm): 598 Product depth (mm): 610 Product length (mm): Net weight (Kg): 45,5

# **TECHNICAL DETAILS**

Energy Efficiency Class: A+++ Energy Consumption (Kw/day): -Water consumption (litres/year): 2800

Noise Level (dBA): 44 Power rate (V): 220-240 Frequency (Hz): 50

### **COLOURS**



40782501

Stainless Steel